



Section 8

FRONT AXLE

List of Illustrations

Title	Figure Number
Front Axle	8-1
Front Wheel Hub, Drum and Bearings	8-2




Figure 8-1 Front Axle




Figure 8-2 Front Wheel Hub, Drum and Bearings



Item	Part Number	Description	Quantity Per Vehicle	
			LHD	RHD
		Figure 8-1		
		FRONT AXLE		
	5950745	Front Axle Assembly (less tie rod, hubs, brushes and drums)	1	1
1	5950814	Knuckle and Brake Flange, Left	1	1
2	5950813	Knuckle and Brake Flange, Right.	1	1
	5950673	Kit, Steering Knuckle (For one end of Axle)	2	2
		Consists Of:		
3		Bearing, Steering Knuckle Thrust.	1	1
4		Shim, Thrust Bearing (.003")	3	3
		Shim, Thrust Bearing (.010")	2	2
5		Draw Key, Light.	1	1
		Draw Key, Heavy.	1	1
6		O-Ring, Knuckle Pin	2	2
7		Bushing, Axle End	2	2
8		Pin, Knuckle, Steering	1	1
9		Fitting, Lubrication	2	2
		Figure 8-2		
		FRONT WHEEL HUB, DRUM AND BEARINGS		
1	5900592	Cover, Wheel Hub	2	2
2	N/S	Nut, Wheel Bearing	2	2
3	N/S	Pin, Cotter	2	2
4	5900677	Washer, Spindle	2	2
5	5900571	Cone, Front Wheel Bearing, Outer	2	2
6	990830	Brake Drum Assy	2	2
7	5900512	Hub and Stud Assy, Front.	2	2
8	5900572	Cone, Front Wheel Bearing, Inner	2	2
9	5900570	Seal, Oil, Front Hub	2	2

[illegible]